

# BATTERY-BOX LV FLEX LITE MINIMUM CONFIGURATION LIST – V 1.5



Compatible Inverter (1- / 3-phase)		Minimum Configuration for Single Phase			Minimum Configuration for Three Phase		
		On Grid	On Grid with Full Backup Power	Off Grid Inrush Use	On Grid	On Grid with Full Backup Power	Off Grid Inrush Use
<b>SMA</b>	SI 4.4M	≥1	≥2	≥2	≥4	≥6	≥6
	SI 6.0H	≥2	≥3	≥3	≥5	≥9	≥9
	SI 8.0H	≥2	≥4	≥4	≥6	≥12	≥12
	Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ V1.3.1.R.						
<b>Victron</b>	MultiPlus 48/500/6	≥1	≥1	≥1	≥1	≥1	≥1
	MultiPlus 48/800/9	≥1	≥1	≥1	≥1	≥1	≥1
	MultiPlus 48/1200/13	≥1	≥1	≥1	≥1	≥2	≥2
	MultiPlus 48/1600/20	≥1	≥1	≥1	≥1	≥2	≥2
	MultiPlus 48/2000/25	≥1	≥1	≥1	≥1	≥3	≥3
	MultiPlus 48/2000/25-50 120V*	≥1	≥1	≥1	≥1	≥3	≥3
	Multiplus 48/3000/35	≥1	≥2	≥2	≥1	≥4	≥4
	Multiplus 48/5000/70	≥1	≥3	≥3	≥2	≥6	≥6
	Multiplus II (GX) 48/3000/35-32	≥1	≥2	≥2	≥1	≥4	≥4
	Multiplus II (GX) 48/5000/70-50	≥1	≥2	≥2	≥2	≥6	≥6
	Multiplus II 120V 48/3000/35-50	≥1	≥2	≥2	≥1	≥4	≥4
	Multiplus II 48/8000/110-100	≥1	≥4	≥4	≥3	≥10	≥10
	Multiplus II 48/10000/140-100	≥1	≥4	≥4	≥3	≥12	≥12
	Quattro 48/3000/35-50/50 120V*	≥1	≥2	≥2	≥1	≥4	≥4
	Quattro 48/5000/70-100/100 120V*	≥1	≥3	≥3	≥2	≥6	≥6
	Quattro 48/10000/140- 100/100 120V*	≥1	≥5	≥5	≥3	≥13	≥13
	Quattro 48/5000/70-100/100	≥1	≥3	≥3	≥2	≥7	≥7
	Quattro 48/8000/110-100/100	≥1	≥4	≥4	≥2	≥10	≥10
	Quattro 48/10000/140- 100/100	≥1	≥5	≥5	≥3	≥13	≥13
	Quattro 48/15000/200- 100/100	≥2	≥6	≥6	≥4	≥16	≥16
	Easysolar 48/5000/70-100 MPPT150/100	≥1	≥3	≥3	≥2	≥6	≥6
	Easysolar II 48/3000/35-32 MPPT250/70 GX	≥1	≥2	≥2	≥1	≥4	≥4
	Easysolar II 48/5000/70-50 MPPT250/100 GX	≥1	≥2	≥2	≥2	≥6	≥6
Multi RS Solar 48/6000	≥2	≥3	≥3	—	—	—	
*. US version Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ V2.52.							



**BYD Company Limited**

www.bydbatterybox.com

Global Sales: batteryboxgrp@byd.com

Global Service: bboxeservice@byd.com

**Battery-Box ZA Service Partner**

Afriplus Energy Group (Pty) Ltd

www.afriplusenergy.co.za

support@afriplusenergy.co.za

**Battery-Box US Service**

BYD AMERICA LLC

www.bydbatterybox.com

us.homeenergy@byd.com

**Battery-Box LATAM Service**

bboxeservLATgrp@byd.com

Version: V 1.5

Update: 2024-04-13



# BATTERY-BOX LV FLEX LITE MINIMUM CONFIGURATION LIST – V 1.5



Compatible Inverter (1- / 3-phase)		Minimum Configuration for Single Phase			Minimum Configuration for Three Phase		
		On Grid	On Grid with Full Backup Power	Off Grid Inrush Use	On Grid	On Grid with Full Backup Power	Off Grid Inrush Use
<b>Selectronic</b>	SPMC480-AU	≥1	≥2	≥2	≥3	≥5	≥5
	SPMC481-AU	≥1	≥3	≥3	≥3	≥8	≥8
	SPMC482-AU	≥2	≥4	≥4	≥6	≥11	≥11
	Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Selectronic SP Link firmware ≥ 14.20.x, SP Pro firmware ≥ V12.x.						
<b>Studer</b>	XTS1400-48	≥1	≥1	≥1	≥1	≥2	≥2
	XTM2600-48	≥1	≥2	≥2	≥1	≥4	≥4
	XTM4000-48	≥1	≥3	≥3	≥2	≥7	≥7
	XTH6000-48	≥1	≥4	≥4	≥2	≥9	≥9
	XTH8000-48	≥2	≥5	≥5	≥3	≥13	≥13
	Next3	—	—	—	≥2	≥6	≥6
	VT-65	≥1	≥1	≥1	≥3	≥3	≥3
	VT-80	≥2	≥2	≥2	≥4	≥4	≥4
	VS-70	≥1	≥1	≥1	≥3	≥3	≥3
	VS-120	≥2	≥2	≥2	≥6	≥6	≥6
	Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware (except Next 3) ≥ R664, inverter firmware (Next 3) ≥ 0.5.0.0.						
<b>SUNSYNK</b>	SUNSYNK-3.6K-SG01LP1-EU	≥1	≥2	≥2	—	—	—
	SUNSYNK-5K-SG01LP1-EU	≥1	≥3	≥3	—	—	—
	SUNSYNK-7.6K-SG01LP1-EU	≥2	≥4	≥4	—	—	—
	SUNSYNK-8K-SG01LP1-EU	≥2	≥4	≥4	—	—	—
	SUNSYNK-3.6K-SG03LP1-EU	≥1	≥2	≥2	—	—	—
	SUNSYNK-4.6K-SG03LP1-EU	≥1	≥2	≥2	—	—	—
	SUNSYNK-5K-SG03LP1-EU	≥1	≥3	≥3	—	—	—
	SUNSYNK-5.5K-SG03LP1-EU	≥1	≥3	≥3	—	—	—
	SUNSYNK-6K-SG03LP1-EU	≥1	≥3	≥3	—	—	—
Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ E41D.							



**BYD Company Limited**  
 www.bydbatterybox.com  
 Global Sales: batteryboxgrp@byd.com  
 Global Service: bboxeservice@byd.com

**Battery-Box ZA Service Partner**  
 Afriplus Energy Group (Pty) Ltd  
 www.afriplusenergy.co.za  
 support@afriplusenergy.co.za

**Battery-Box US Service**  
 BYD AMERICA LLC  
 www.bydbatterybox.com  
 us.homeenergy@byd.com

**Battery-Box LATAM Service**  
 bboxeservLATgrp@byd.com

Version: V 1.5  
 Update: 2024-04-13



# BATTERY-BOX LV FLEX LITE MINIMUM CONFIGURATION LIST – V 1.5



Compatible Inverter (1- / 3-phase)		Minimum Configuration for Single Phase			Minimum Configuration for Three Phase			
		On Grid	On Grid with Full Backup Power	Off Grid Inrush Use	On Grid	On Grid with Full Backup Power	Off Grid Inrush Use	
Deye	SUN-3.6K-SG01/03LP1-EU	≥1	≥2	≥2	≥1	≥5	≥5	
	SUN-5K-SG01/03LP1-EU	≥1	≥3	≥3	≥1	≥6	≥6	
	SUN-6K-SG01/03LP1-EU	≥1	≥3	≥3	≥1	≥7	≥7	
	SUN-7.6K-SG01LP1-EU	≥1	≥4	≥4	≥1	≥9	≥9	
	SUN-8K-SG01LP1-EU	≥1	≥4	≥4	≥1	≥9	≥9	
	SUN-12K-SG01LP1-EU	≥1	≥6	≥6	≥1	≥14	≥14	
	SUN-14K-SG01LP1-EU	≥1	≥7	≥7	≥1	≥16	≥16	
	SUN-16K-SG01LP1-EU	≥1	≥8	≥8	≥1	≥18	≥18	
	SUN-5K-SG01LP1-US	≥1	≥3	≥3	≥1	≥6	≥6	
	SUN-6K-SG01LP1-US	≥1	≥3	≥3	≥1	≥7	≥7	
	SUN-7.6K-SG01LP1-US	≥1	≥4	≥4	≥1	≥9	≥9	
	SUN-8K-SG01LP1-US	≥1	≥4	≥4	≥1	≥9	≥9	
	Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ C351.							
	SUN-3K-SG04LP1-EU	≥1	≥2	≥2	≥1	≥4	≥4	
	SUN-3.6K-SG04LP1-EU	≥1	≥2	≥2	≥1	≥5	≥5	
	SUN-5K-SG04LP1-EU	≥1	≥3	≥3	≥1	≥6	≥6	
	SUN-6K-SG04LP1-EU	≥1	≥3	≥3	≥1	≥7	≥7	
	SUN-3.6K-SG05LP1-EU	≥1	≥2	≥2	≥1	≥5	≥5	
	SUN-5K-SG05LP1-EU	≥1	≥3	≥3	≥1	≥6	≥6	
	SUN-6K-SG05LP1-EU	≥1	≥3	≥3	≥1	≥7	≥7	
	SUN-7.6K-SG05LP1-EU	≥1	≥4	≥4	≥1	≥9	≥9	
	SUN-8K-SG05LP1-EU	≥1	≥4	≥4	≥1	≥9	≥9	
	SUN-5K-SG04LP3-EU	—	—	—	≥1	≥2	≥2	
	SUN-6K-SG04LP3-EU	—	—	—	≥1	≥3	≥3	
	SUN-8K-SG04LP3-EU	—	—	—	≥1	≥3	≥3	
	SUN-10K-SG04LP3-EU	—	—	—	≥1	≥4	≥4	
	SUN-12K-SG04LP3-EU	—	—	—	≥1	≥5	≥5	
	SUN-8K-SG02LP2-US	≥1	≥4	≥4	—	—	—	
	Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ 1001-C015.							



**BYD Company Limited**  
 www.bydbatterybox.com  
 Global Sales: batteryboxgrp@byd.com  
 Global Service: bboxeservice@byd.com

**Battery-Box ZA Service Partner**  
 Afriplus Energy Group (Pty) Ltd  
 www.afriplusenergy.co.za  
 support@afriplusenergy.co.za

**Battery-Box US Service**  
 BYD AMERICA LLC  
 www.bydbatterybox.com  
 us.homeenergy@byd.com

**Battery-Box LATAM Service**  
 bboxeservLATgrp@byd.com

Version: V 1.5  
 Update: 2024-04-13



# BATTERY-BOX LV FLEX LITE MINIMUM CONFIGURATION LIST – V 1.5



Compatible Inverter (1- / 3-phase)		Minimum Configuration for Single Phase			Minimum Configuration for Three Phase		
		On Grid	On Grid with Full Backup Power	Off Grid Inrush Use	On Grid	On Grid with Full Backup Power	Off Grid Inrush Use
GoodWe	GW3648D-ES	≥2	≥3	≥3	—	—	—
	GW5048D-ES	≥2	≥2	≥2	—	—	—
	GW3048-EM	≥1	≥1	≥1	—	—	—
	GW3648-EM	≥1	≥1	≥1	—	—	—
	GW5048-EM	≥1	≥1	≥1	—	—	—
	GW3600S-BP	≥2	≥2	≥2	—	—	—
	GW5000S-BP	≥2	≥2	≥2	—	—	—
Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ V11.							
Phocos	PSW-H-5kW-120/48V	≥2	≥3	≥3	≥6	≥8	≥8
	PSW-H-6.5kW-120/48V	≥3	≥4	≥4	≥7	≥9	≥9
	PSW-H-5kW-230/48V	≥2	≥3	≥3	≥6	≥8	≥8
	PSW-H-8kW-230/48V	≥3	≥4	≥4	≥8	≥10	≥10
Battery firmware: BMU ≥ V1.22, BMS ≥ V1.13; Inverter firmware ≥ 06.19 (U2 firmware).							
RAION	J5	≥2	≥3	≥3	≥5	≥6	≥6
	M8	≥3	≥4	≥4	≥7	≥9	≥9
Battery firmware: BMU ≥ V1.24, BMS ≥ V1.14; Inverter firmware of J5: U1≥ 50.05; U2≥ 19.17, Inverter firmware of M8: U1≥ 46.09 or 72.05; U2≥ 12.25.							
Solis	S6-EH1P3K-L-Pro	≥1	≥1	≥2	≥1	≥3	≥4
	S6-EH1P3.6K-L-Pro	≥1	≥2	≥2	≥1	≥4	≥5
	S6-EH1P5K-L-Pro	≥1	≥2	≥3	≥1	≥5	≥6
	S6-EH1P6K-L-Pro	≥1	≥2	≥3	≥1	≥6	≥7
	S6-EH1P3K-L-EU	≥1	≥1	≥1	—	—	—
	S6-EH1P3.6K-L-EU	≥1	≥2	≥2	—	—	—
	S6-EH1P4.6K-L-EU	≥1	≥2	≥2	≥1	≥4	≥4
	S6-EH1P5K-L-EU	≥1	≥2	≥2	≥1	≥5	≥5
	S6-EH1P6K-L-EU	≥1	≥2	≥2	≥1	≥6	≥6
Battery firmware: BMU ≥ V1.24, BMS ≥ V1.14; Inverter firmware ≥ 320020.							

**Note:**

- Max. 64 modules can be connected in parallel.
- Inrush Power: Each Inverter has their Inrush power for off grid applications, please make sure to consult with inverter brands for the right value of correspondences; On-grid with full backup power equals to off-grid inrush power use.
- Configurations marked in gray are not released yet and are not allowed to be installed yet. Those configurations are planned and subject to change.



**BYD Company Limited**  
 www.bydbatterybox.com  
 Global Sales: batteryboxgrp@byd.com  
 Global Service: bboxeservice@byd.com

**Battery-Box ZA Service Partner**  
 Afriplus Energy Group (Pty) Ltd  
 www.afriplusenergy.co.za  
 support@afriplusenergy.co.za

**Battery-Box US Service**  
 BYD AMERICA LLC  
 www.bydbatterybox.com  
 us.homeenergy@byd.com

**Battery-Box LATAM Service**  
 bboxeservLATgrp@byd.com

Version: V 1.5  
 Update: 2024-04-13

